



Size Information:

The shoes from Werner Kern Dance shoes run a bit larger than normal street shoes. They have to fit tight, because the nappa or suede leather is becoming softer and wider after dancing. In the list below you see the corresponding sizes.

LADIES

MEN

Only for the styles:
Sonia 5,5 cm, Ilona 5 cm
und Rachel 3,4 cm!

For the rest of all dance shoes from Werner Kern/
 Anna Kern/ Nueva Epoca/
 WK Bridal

UK	=	EU	UK	=	EU	UK	=	EU
1	=	34	1	=	33½	5	=	38½
1½	=	34½	1½	=	34	5½	=	39½
2	=	35½	2	=	34½	6	=	40
2½	=	36	2½	=	35½	6½	=	40½
3	=	36½	3	=	36	7	=	41½
3½	=	37½	3½	=	36½	7½	=	42
4	=	38	4	=	37½	8	=	42½
4½	=	38½	4½	=	38	8½	=	43½
5	=	39½	5	=	38½	9	=	44
5½	=	40	5½	=	39½	9½	=	44½
6	=	40½	6	=	40	10	=	45½
6½	=	41½	6½	=	40½	10½	=	46
7	=	42	7	=	41½	11	=	46½
7½	=	42½	7½	=	42	11½	=	47½
8	=	43½	8	=	42½	12	=	48
8½	=	44	8½	=	43½	12½	=	48½
9	=	44½	9	=	44	13	=	49½

